



DUŠO KABINOS VERONA R23 SURINKIMO INSTRUKCIJA





A		X4	H		X1	O	 ST4X16	X16
B		X2	I		X4	P	 ST4X12	X4
C		X2	J		X4	Q	 STOR ST4X12	X6
D		X2	K		X4	R		X1
E		X2	L		X2	S	 ST4X8	X2
F		X1	M		X1	T		
G		X4	N	 ST4X30	X8	U		

